

Installation Instructions for the GFT-16 or 18

GFT-16 is for 16" on center and the GFT-18 if for 24" on center studs.

A - Using a stud finder, determine the center of the studs and mark each stud.

B - Then measure about 6-8" down from the ceiling and draw a mark in the center so that you make the cut as drawn.

C - Draw a 12.5" for 16 or 14.5" for 18 square from the center point. Drill out the 4 corners all the way through the outside wall.

D - Draw a square for the inset of the fan on the outside centered of the pilot holes. Cut out each side with your drywall saw and or saws-all.

E - Next install the GFT-16 or 18 fan into the square hole and secure into the stud on one side and the other using a drywall anchor. Do the same with the grill on the outside with louvers pointing down.

F - Center the intake grills in the raised panel in the garage door. Trace the inside of the intake grill with a pencil and drill each corner with a 1/2" drill so you can get tin snips in and cut out the hole. Screw or pop rivet the intake vents on to the door. Place one on each end of the garage door and in the bottom panel for maximum air flow.

G - Wire the fan and place the timer in line where you want it then run the wire over to the nearest outlet and secure the line with staples. Attach the plug to the wire and plug in.

Please call 855-431-4326 for any tips on the GFT-16 or 18 Garage Fan Installation.

Thank You For Your Purchase - Enjoy!

If you take pictures of your installation and give us a testimonial for our website, e-mail them to us We'll send you our "**America's Best**" water heater jacket FREE! \$39.99 Value! Send to ray@coolmygarage.com.

