

Wall Vent Installation Sheet

Using a stud finder, determine the center of the studs and mark each stud. This vent will fit between 16" on center or 24 " on Center studs. If you have 16" on center the vent will screw right into the studs. For 24" on center you can use a stud on one side to secure the vent and use drywall anchors for the other side.



Determine where you want the wall vent and trace the inset frame and drill each corner all the way through the exterior wall. Make the cut in the drywall as drawn.



Cut the exterior wall to match the interior hole. Cut out each side with your drywall saw and or saws-all.

Next install the wall vent into the rectangle hole and secure into the studs with the screws provided. Do the same with the grill on the out side with louvers pointing down using the appropriate anchors for the exterior.



Please call 855-431-4326 for any tips or questions on installing the Through Wall Intake Vent.

Thank You For Your Purchase - Enjoy!

If you take pictures of your installation and give us a testimonial for our website, e-mail them to us We'll send you our "**America's Best**" water heater jacket FREE! \$39.99 Value! Send to ray@coolmygarage.com.

